


RULES FOR DETERMINATION OF DEFECTS


This edition shall enter into force as of 01.01.2026 Annex No. 2 to the General Terms and Conditions of the Semi-Trailers Lease Agreement

This document provides visual examples of:


- i) normal wear and tear, marked with a green symbol featuring an upward-pointing thumb;
- ii) damage that is not considered normal wear and tear and is classified as defects, marked with a red symbol featuring a downward-pointing thumb.



Vehicle exterior
Light soiling, exterior



Vehicle interior
Signs of use, clean and complete




Roof tarpaulin
Damaged roof tarpaulin,
water puddle on the floor



Vehicle exterior
Curtain vandalised by graffiti



Vehicle interior
Unclean, untidy return condition



Sliding roof
Defect sliding roof



Inner bulkhead

Inner bulkhead with signs of use



Corner bumpers

Corner bumpers with signs of use



Corner bumpers

Missing corner bumpers, deformed fitting




Inner bulkhead

Inner bulkhead with damages



Corner bumpers

Damaged corner bumpers



Corner bumpers in roller version

Defective corner bumpers

**Bulkhead corner support**

Bulkhead corner support with signs of use and lock clamp

**Rear door**

Damaged rear frame (left side)

**Side post / rear frame**

Damaged rear frame (right side)

**Bulkhead corner support**


Bulkhead corner support with signs of use, lock clamp missing

**Rear door**

Punctures in the rear door panel

**Rear door**

Damaged inner rear door (right side)




Tarpaulin strap

Straps with signs of use (rear left side)



Tarpaulin

Tarpaulin with signs of use



Tarpaulin

Cut in tarpaulin larger than 3 cm




Tarpaulin strap

Damaged strap (rear right side)



Tarpaulin

Non acceptable standard of repair



Curtain spanners

Damaged curtain spanners



Lead in plate

Correctly executed repair




Landing gear

Landing gear with signs of use



Flange

Damage to rim flange



ABS-socket

Missing cover,
bent couplings



Landing gear

Damaged landing gear



Tyre

Damaged face of tyre



Rear marker lights

Defective rear marker lights




Control unit brakes / air suspension

Control unit with signs of use




Document box and customs cable

Document box and customs cable
without damages




Frame cross-piece

Bent frame cross-piece through wrongly
positioned vehicle jack



Control unit brakes / air suspension

Missing control button



Document box and customs cable

Missing cover from document box
and missing customs cable






Mudguards

Damaged mudguards



Underride guard

Underride guard with signs of use



Lateral marker lights

Demolished marker lights



Mud flaps

Missing mud flaps



Underride guard

Deformed underride guard



Rear light unit

Broken lens



Toolbox

Toolbox with signs of use



Alu-drop-in slats

Bent drop-in slats




Spare wheel holder

Deformed spare wheel holder



Toolbox

Damaged toolbox



Alu-drop-in slats

Torn-up drop-in slats




Ladder

Deformed retainer, ladder without function



Sideguards

Sideguards with signs of use



Sideguards

Bent frame fitting



Pallet box

Pallet box with signs of use




Sideguards

Deformed sideguards



Wheel chock

Deformed wheel chock



Pallet box cover

Deformed pallet box cover






Registration and load safety certificate

Complete documentation



Wheel chock

Missing wheel chock



Drop-in slats

Missing drop-in slats




Fire extinguisher box

Fire extinguisher box not complete



Quantity of additional stanchions

Missing additional stanchions



Stack-room for Joloda accessory

Incomplete accessory